

**PREMIUM CABIN AIR FILTER
INSTALLATION GUIDE**

Particulate Filter Replacement for your truck

Filter Location: Inside cab under passenger side dashboard

Tools Required: Check owner's manual

Procedure:

1. Remove filter cover
2. Remove used filter
3. Install new Extreme Clean HD[™] cabin air filter
4. Make certain air flow arrow is pointing towards truck cabin
5. Install cover

For more information on
Luber-finer[®] Extreme Clean HD[™] products,
please visit our website



**FILTRO PREMIUM PARA CABINA
GUÍA DE INSTALACIÓN**

Sustitución de filtro de partículas para su camión

Ubicación del filtro: Dentro de la cabina, debajo del tablero, del lado del pasajero

Herramientas necesarias: Revise el manual del propietario

Procedimiento:

1. Retire la tapa del filtro
2. Retire el filtro usado
3. Instale el nuevo filtro Extreme Clean HD[™] de aire para cabina
4. Asegúrese de que la flecha de flujo de aire apunte hacia la cabina del camión
5. Instale la tapa

**PRIME PURIFICATEUR D'AIR
GUIDE D'INSTALLATION**

Remplacement du filtre à particules pour votre camion

Emplacement du filtre : Dans la cabine de conduite sous le tableau de bord du côté passager

Outils requis : Vérifier le manuel du propriétaire

Procédure :

1. Retirer le couvercle du filtre
2. Retirer le filtre usagé
3. Installer le nouveau filtre à air Extreme Clean HD^{MC} pour cabine
4. Vous assurer que la flèche du flux d'air est dirigée vers la cabine du camion
5. Installer le couvercle